

ATTENTION!

You must first determine if your Superclamp is appropriate to cut.

1. Remove rubber pad on the side of the Superclamp without the lever. (Illustration 1)

2. Locate an additional set of holes for the fasteners (Illustration 2). If your Superclamp does **NOT** have these holes, you **CANNOT** cut the clamp.

2. Using a saw with a fine tooth blade, cut the Superclamp on the outer edge of the rib. This line will be approximately 1.75" from the edge. (Illustration 2 - green dotted line)

- 3. Reinstall the rubber pad using the previously unused holes.
- 4. Trim the excess part of the rubber pad with a sharp utility knife.

